



DISPENSER / PAPER / COSMETIC PRODUCTS



www.jm-metzger.de

HS1200



ARM LEVER DISPENSER



JM-Metzger GmbH
Nordstraße 45
74219 Möckmühl
+49(0) 6298 93 77 00
info@jm-metzger.de



JM-Paper Converting SLU
Calle Dinamarca 9
Igalada 08700
+49(0) 6298 93 77 00
info@jm-metzger.de

JM-Metzger GmbH
Nordstraße 45
74219 Möckmühl
info@jm-metzger.de
+49(0) 6298 93 77 00
www.jm-metzger.de

ARM LEVER DISPENSER

2 // 6

ARM LEVER DISPENSER

Measurements in mm (W x H x D):

85 x 255 x 180

Colour: white

210 pieces/pallet

Art.-No. **Price in €**

HS1200W **29,80**

Also available in those colours:



white/black
HS1200WS



white/blue
HS1200WB



white/green
HS1200WG



white/red
HS1200WR

ARM LEVER DISPENSER

Measurements in mm (W x H x D):

85 x 255 x 180

Colour: black

210 pieces/pallet

Art.-No. **Price in €**

HS1200S **29,80**

Also available in those colours:



black/white
HS1200SW



black/blue
HS1200SB



black/green
HS1200SG



black/red
HS1200SR



REFILL MATERIAL // CARTRIDGES

3 // 6



MANORAPID® R.F.U. HAND SANITIZER

Quantity: 1000 ml

6 pcs. / pack - 540 pcs. / pallet

Alcoholic hand sanitizer, filled in 1000 ml cartridges with a suitable spray pump.

Manorapid® r.f.u. is a ready-to-use, alcoholic solution for Hand disinfection.

The preparation is highly effective Equipped with a moisturizer that works even with frequent use Application ensures excellent skin compatibility.

Art.-No. **Price in €**

HD1200 Hand Sanitizer **59,40**
9,90/cartridge

HAND SOAP

Quantity: 1000 ml

6 pcs. / pack - 540 pcs. / pallet

Lotion Soap is a hand cleansing lotion with a pleasant fresh fragrance and pearlescent effect.

Skin care ingredients leave the skin feeling comfortable after use.

Art.-No. **Price in €**


CLC1200 Hand soap **38,70**
6,45/cartridge

INSTRUCTION MANUALS

4 // 6


1. MOUNT THE WALL BRACKET:

Mount the wall bracket with at least 3 screws or use the adhesive strip.



2. ATTACH DISPENSER:

Slide the dispenser onto the wall bracket from above and snap it into place.




3. SET THE DOSING QUANTITY:

The dosing quantity is set with the stroke setting (white pin).

Depending on the desired quantity, insert the pin into the openings under the dispenser lever.

Front pin 1 ml / rear pin 2 ml



4. INSERT FILLER

Press the dispenser bottle into the clamp, until it is securely anchored.

